

DIGITAL COIN COUNTER / MONEY SAVING JAR WITH LCD DISPLAY




Product overview



1. LCD display
2. Coin slot
3. Add coin slot
4. Subtract coin slot

Battery installation



- When changing the batteries, adult supervision is recommended
- For the best performance, use alkaline batteries
- You can find the battery holder at the bottom of the lid
- Remove the screw using a screwdriver
- Insert two AAA batteries, in the polarity direction shown on the diagram above
- Put the battery door back in place
- Fasten the lid by rotating clockwise

Note: when the LCD starts to fade, it is time to change the batteries. The display memory stays on only 15s after removing the batteries, so make sure you have two new AAA batteries ready before removing the old batteries.

Using your digital coin counter

- Adding coins: push the coins through the slot one at the time. The LCD display will blink showing the value of each coin. When it stops blinking, it will show the total value.
- Alternate ways to add money: remove the lid. Add coins to the jar. Attach the lid. Press the "Add coin button" until it displays the amount of coins you've added.
- Subtracting coins: remove the lid. Subtract coins from the jar. Press the "Subtract coins button" until it displays the total amount of coins subtracted.
- Resetting the LCD display: insert the end of the paper clip or similar object into the reset hole located on the underside of the lid.

Precautions

- Clean the digital coin counter with a slightly damp cloth. Never soak or submerge in water.
- Store in a cool, dry place, away from direct sunlight.
- Do not mix old and new batteries.
- Do not mix standard, alkaline, and rechargeable batteries.
- Always insert the batteries using the correct polarity.