Xiaomi 70mai Dash Cam Lite - 1080p, WiFi - Black




Activating the 70mai Dash Cam Lite


The 70mai Dash Cam Lite must be activated using the 70mai app. To download and install the app, search for "70mai" in Google Play Store (Android) or App Store (iOS). Or you can download the app by scanning the QR code below.



Please select "Add Device" in the 70mai app and complete the activation according to the prompts.

Product overview





- 1. Indicator light
- 2. Function buttons
- 3. Power button
- 4. USB interface
- 5. Memory card slot
- 6. Speakers
- 7. Camera

Installation


1. Install the electrostatic sticker

- Clean your windshield and put the electrostatic sticker on the recommended area as shown in the figure below. Make sure you remove air bubbles between the sticker and the glass.




2. Install the bracket

- Lock the bracket to the Dash Cam, as shown in the figure below. You will hear a snap when it is in place.




3. Stick the camera mount to the windshield

- Remove the protective cover from the mount and stick the mount's base to the center of the electrostatic sticker. Make sure your Dash Cam body is parallel to the ground. Press the mount to attach it to the electrostatic sticker tightly.



4. Connect USB cable to the cigarette lighter

- Align the cable with the top edge of the windshield and fasten it along the passenger's side and the glovebox as shown below. Connect the cable to the power adapter and insert the adapter into the cigarette lighter receptacle.



5. Adjust the Dash Cam angle

- Turn on the Dash Cam and adjust the camera angle up and down against the preview screen to ensure that the camera is facing the front.

Specifications:

- Sensor: Sony IMX307

- Aperture: f2.0

- Video resolution: 1920x1080

Frame rate: 30fpsVideo format: MOV

- Image resolution: 1920x1080

- Image format: JPEG

- Viewing angle: 130 degrees

Display: 320x240 IPSBattery: 500mAh Li-ionBattery life: up to 24h

- Supported memory cards: MicroSD up to 64GB (Class10 and above)