

User Manual for Adjustable 3D LED Light Digital Electric Clock



Specification

- Material: Acrylonitrile butadiene styrene
- Dimensions: 21,5cm x 8,5cm x 3,8cm
- Charging cable length: 1,8m

Buttons introduction

Set button: under time mode, press this button to set time, date, temperature, alarm 1/2/3, and then long-press the set button to confirm.

Up button: short-press this button to enter the Adjust mode. Long-press for fast adjustment. Under alarm mode, short-press to open/close the alarm function.

Down button: under settings mode short-press this button to enter adjustment mode. Long-press for fast adjustment.

Display modes

To select the display mode you want press the Up button and you can choose one of the three modes:

DP-1 mode: LED display time, date, and temperature changes after one another. After 10 seconds it will go back to the time mode.

DP-2 mode: by default displays time, but you can change it and it will constantly display the mode you choose.

DP-3 mode: by default displays time and if you change to another mode and there is no activity for 15 seconds it will go back to the time mode.

Functions

The clock function: the default format is 12-hour, but you can change it to 24-hour format if you go to settings, and press the Up button.

The time display mode: long-press the Set button for 2 seconds to enter the clock settings. Press the Up/Down buttons to adjust the time. For faster adjusting, long-press the Up or Down buttons. The settings order is time format (12/24) - hours - minutes - save and exit.

The date mode: the date shows month/date by default. To check the year, you have to enter the date settings. While in the date settings, you can adjust the date by long-pressing the Set button. Use the Up and Down buttons to set the date, and for faster setting long-press the Up or Down buttons. The year can be chosen between 2000 and 2099.

Alarm function: there is a total of 3 alarms that can be set. Go to the alarm mode, press the Up button to turn the alarm on or off, and long-press the Set button to enter the alarm settings. Settings order is hours - minutes - save and exit. When the alarm goes off, press any button to stop it. If you don't press anything it will ring for 1 minute.

Automatic brightness adjusting: the brightness is automatically adjusted based on the time of the day. It goes from 70% between 7 PM and 6 AM to 100% between 6 AM to 7 PM.