4-in-1 Digital Alarm Clock with Wireless Charger - 15W



Specifications:

- Phone charging: 5/7/10/15W
- AirPods charging: 5W
- Apple Watch charging: 2W
- Dimensions: 165x100x14mm
- Weight: 230g


Instructions:

1. Plug the included USB-C charging cable in the USB-C IN port, and the other cable end plug in your power adapter (for optimal performance, use at least a 20W fast charger).

2. Place your smartphone on the anti-skid pad vertically or horizontally to start charging

3. Rotate and open the watch bracket, and place your Apple Watch correctly to start charging

4. The earphone support plate is magnetic, you need to insert it into the slot as shown in the picture bellow



Charging status:

 Smartphone charging - When the power is turned on, the icon flashes 3 times to enter standby mode. During charging, the icon is turned on constantly. When incompatible equipment is detected or the phone is not aligned, it flashes.
Apple Watch charging - When the power is turned on, the icon flashes 3 times to enter standby mode. During charging, the icon is turned on constantly. When incompatible equipment is detected or the watch is not aligned, it flashes.
Wireless earphones charging - When the power is turned on, the icon flashes 3 times to enter standby mode. During charging, the icon is turned on, the icon flashes 3 times to enter standby mode. During charging, the icon is turned on, the icon flashes 3 times to enter standby mode. During charging, the icon is turned on constantly. When incompatible equipment is detected or the earphones are not aligned, it flashes.

Clock settings:

1. When the product is powered on, the LED display changes rapidly from 0000 to 9999, and a 'di' prompt tone appears later to enter the normal clock mode. By default, 'AM12:00' is displayed, and the temperature is displayed on the same screen. In the normal clock state, press the SET key, and you can set it in the following order: time \rightarrow date \rightarrow alarm clock 1 \rightarrow alarm clock 2 \rightarrow alarm clock 3.

2. Time setting: long press the SET key for about 2 seconds \rightarrow 12 / 24-hour system \rightarrow hour \rightarrow minute \rightarrow exit (Press "+" and "-" to adjust, and long press to add or subtract numbers quickly).

3. When setting the time, if it stops for 15 seconds, it will exit automatically .

Date settings:

1. Under normal clock state \rightarrow short press the SET key \rightarrow date setting interface \rightarrow long press the SET key \rightarrow Year \rightarrow Month \rightarrow Day \rightarrow Exit (In the setting, press "+" and "-" to adjust the day and month).

Display settings:

1. In the display time state, short-press the SET key 5 times to enter the DP setting mode.

2. DP-1 mode: the screen automatically converts the time and date. The time is displayed for 10 seconds and the date is displayed for 2 seconds.3. DP-2 mode: display time only.

Temperature settings:

1. The real-time temperature can be displayed. Press and hold the DOWN key for 2 seconds to switch C/F.

Alarm settings:

1. In the time display state, short-press the SET key twice to display the alarm clock. Press the "+" button to turn on or off the alarm clock.

Under the alarm interface, long press the SET key for about 2 seconds to enter the alarm mode and set the time. After setting the alarm time, short-press the SET button to select the alarm date through "+" and "-" (you can set the alarm at any time from Monday to Friday, Monday to Saturday, Monday to Sunday, and Saturday to Sunday).
A total of 3 alarm clocks can be set. Short press the SET key to select A1, A2, and A3 alarm clocks respectively.

Battery save mode

1. Power saving (- - Sd) is turned off by default when the power is turned on. In the display time state, short-press the "-" key to select on (onSd) / off (- - Sd) power saving mode.

2. Power saving mode: without pressing the key for 10 seconds, the display goes out, enters the power saving mode, the system still maintains the normal timing and temperature, saves the previous settings, and wakes up the screen when there is a key operation .

3. Voice control function: turn off the power-saving mode. In the state of the LED display screen, make a loud sound or touch the product to wake up the screen

Reset

- Press the "+" and "-" keys for more than 4 seconds at any time, and the clock will automatically reset and restart.